



FOR
FRONT LEFT




A (x2)



FOR
REAR LEFT



B (x2)



C (x6)



M8 (x8)



ERKUL[®]
Products & Quality




HONDA CRV 2006-2012 RUNNING BOARD



instructions

FRONT BRACKET



REAR BRACKET

